


Montageanleitung

Ⓒ mounting instruction Ⓕ Notice de montage Ⓒ Instrukcja montażu
Ⓔ Instrucciones de montaje Ⓖ Istruzioni di montaggio


RES-FLEX



RIDI Leuchten GmbH
Hauptstrasse 31 - 33 · D-72417 Jungingen
Tel. 07477/872-0 · Fax 07477/872-48
kontakt@ridi-group.de · www.ridi-group.com

Pos. 0: Flux min.

Pos. 9: Flux max.



- Ⓓ Werkseinstellung: Maximaler Lichtstrom
- ⒼⒷ Factory setting: maximum light distribution
- Ⓕ Réglage d'usine : flux lumineux maximal
- Ⓗ Ustawienie fabryczne: maksymalny strumień świetlny
- Ⓔ Ajuste de fábrica: flujo luminoso máximo
- Ⓘ Impostazione predefinita: flusso luminoso massimo

Pos	I (mA)	Flux (lm)	P (W)
0			
1			
2			
3			
4			
5			
6			
7			
8			
9			



Position 0-9
I (mA)
Flux (lm)
P (W)