

I

D) Für die Installation und für den Betrieb der Leuchten sind die nationalen Sicherheitsvorschriften zu beachten.

GB

Please note national safety instructions for installation and operation of this luminaire.





F

'Pour l'installation et le fonctionnement des luminaires il est impératif de respecter les normes nationales de sécurité en vigueur'


PL

W celu prawidłowej instalacji i poprawnego działania oprawy należy przestrzegać krajowych przepisów bezpieczeństwa.


IRL-T16 135/49/80 W	1790	125	1600
IRL-T16 128/54 W	1490	110	1300
IRL-T16 121/39 W	1190	95	1000
IRL-T16 114/24 W	890	80	700
Typ	L	NS	L4




II




III



IV





RIDI Leuchten GmbH
Hauptstrasse 31 - 33 · D-72417 Jungingen
Tel. 07477/872-0 · Fax 07477/872-48
kontakt@ridi.de · www.ridi.de

RIDI Lighting Ltd · 889 Marshgate Centre · Harlow Business Park · Harlow, CM19 5QP · 01279 450852 · info@ridi.co.uk

