


## Montageanleitung

Ⓒ mounting instruction Ⓕ Notice de montage Ⓒ Instrukcja montażu  
Ⓔ Instrucciones de montaje Ⓘ Istruzioni di montaggio



## RES-FLEX





RIDI Leuchten GmbH  
Hauptstrasse 31 - 33 · D-72417 Jungingen  
Tel. 07477/872-0 · Fax 07477/872-48  
kontakt@ridi-group.de · www.ridi-group.com

Pos. 0: Flux min.

Pos. 9: Flux max.



- Ⓓ Werkseinstellung: Maximaler Lichtstrom
- ⒼⒷ Factory setting: maximum light distribution
- Ⓕ Réglage d'usine : flux lumineux maximal
- Ⓗ Ustawienie fabryczne: maksymalny strumień świetlny
- Ⓔ Ajuste de fábrica: flujo luminoso máximo
- Ⓘ Impostazione predefinita: flusso luminoso massimo



Position 0-9  
I (mA)  
Flux (lm)  
P (W)