

## D TALU LED-Einbaustrahler 1er Set dimmbar Plug-and-play

### ⚠ Stromschlaggefahr!

Beauftragen Sie mit der Installation eine Elektrofachkraft. Für Strahler, die nicht gemäß den europäischen Sicherheitsrichtlinien installiert wurden, entfällt jeder Haftungsanspruch.

### ⚠ Brandgefahr!

Strahler nicht mit wärmedämmenden Stoffen abdecken.




### ⚠ Achtung!

Für alle Anschlüsse sekundärseitig des Konverters ist ausschließlich die mitgelieferte Niedervoltleitung zu verwenden.

Der Strahler ist zur Montage auf normal entflammaren Oberflächen geeignet, z.B. auf Holz und Werkstoffen auf Holzbasis mit mehr als 2 mm Stärke. Strahler nur nach unten strahlend montieren.

### Einbau mit Haltefedern:

Die Haltefedern müssen nach der Installation in horizontaler Position liegen, nicht vertikal (Abb. 1).



Technische Daten: siehe Aufkleber auf Einbaustrahler.

### Inbetriebnahme:

Betreiben Sie den Schutzklasse III Einbaustrahler TALU Plug-and-play ausschließlich an dem dafür vorgesehenen Konstantstrom-Konverter (im Lieferumfang enthalten).



Equiv.  
**SELV**

CE-konform mit den zutreffenden europäischen Richtlinien.




## Montage

### ⚠ Stromschlaggefahr!

Vor der Installation Spannung abschalten. Sicherstellen, dass die Spannung nicht versehentlich wieder eingeschaltet werden kann.

1. Loch am Montageort sägen. Der Durchmesser beträgt 68 mm.



2. Elektrischer Anschluss:  
TALU Plug-and-play Einbaustrahler, mithilfe des mitgelieferten Steckverbinders, an die sekundärseitige Leitung des Konverters, mit passendem Gegenstück des Steckverbinders, anschließen. An die Primärseite des Konverters die vorhandene 230V AC Netzspannung anschließen (Abb. 2).




Abb. 2


3. Federn des Einbaustrahlers zusammendrücken und diesen in das ausgesägte Loch einsetzen (Abb.3).



Abb. 3

4. Spannung einschalten.

Dieses Produkt enthält eine Lichtquelle der Energieeffizienzklasse F.



# GB TALU LED-downlight dimmable single-set plug-and-play

## ⚠ Danger of electrocution!

Be sure to have a professional electrician complete installation. There is no warranty coverage for any lamps installed without observing European safety directives.

## ⚠ Fire hazard!

Do not cover lamps with heat insulating materials.




## ⚠ Caution!

Only the supplied low voltage cable must be used for all connections on the secondary side of the converter.

The Downlight is suitable for mounting on normally flammable surfaces such as wood and particle board materials which are more than 2 mm thick. Only install downlights so that they shine downwards.

### Installation of mounting springs:

Make sure that the springs are in the right position (fig. 1).



Technical data: See label on downlight.

### Installation:

Only operate the protection class III recessed downlight TALU plug-and-play with the constant Current converter provided for it (including in delivery).



Equiv.  
**SELV**

CE compliant with the applicable European directives.




## Assembly

### ⚠ Stromschlaggefahr!

Switch off voltage prior to installation. Ensure that voltage cannot be accidentally switched on again.

1. Saw a hole at the installation location. The diameter is 68 mm.



2. Electrical connection:  
Connect the TALU plug-and-play recessed downlight to the secondary side line of the converter using the connector supplied with the matching counterpart of the connector. Connect the existing 230V AC mains voltage to the primary side of the converter (fig. 2).




fig. 2

3. Press the springs together and place the downlight in the sawn out hole (fig. 3).



fig. 3

4. Switch on the mains voltage.

This product contains a light source of energy efficiency class F.

