

VISION



Motion detector **Fitting instructions**

Description

Purpose and application

The VISION motion detector detects the movements of people. The sensor is attached to ceilings and is ideal for mounting at great heights and for wide detection areas. The unit is mounted directly in a dry lining box or using the "Mounting Adapter", optionally available from OSRAM, to ensure that the installation conforms to the CE guidelines.

The VISION motion detector can be connected to any control component with a floating input that is designed for permanent contact (switch).

Function

The motion detector detects motion within a detection area of 360° and switches on the connected luminaires when motion is registered. When motion is no longer registered, the luminaires switch off after an adjustable delay period.

Design

The sensor is made up of the following components:

- Housing (A)
- Connection cable (B):
- L: phase (black)
- N: neutral conductor (blue)
- Floating switch contact (2x white)
- Motion sensor (C)
- Button for setting the delay (D)
- . LED (E)

Installation

Safety instructions

The motion detector must only be installed and put into opera-tion by a qualified electrician. The applicable safety regulations and accident prevention regulations must be observed.

WARNING! /!\

Exposed, live cables or damaged housing

Danger of electric shock!

Only work on the motion detector when it is de-energised.

CAUTION!

Destruction of the motion detector and other devices through incorrect mounting!

- · Adhere to the connection diagram.
- · Do not exceed the maximum line length.
- Do not route sensor lines together with power supply or lamp lines.

IX 2009 VISION_ma0911en_we1.01.indd

OSRAM GmbH Kunden Service Center Customer-Service-Center (CSC) Steinerne Furt 62 86167 Augsburg Germany Tel : +49 (0) 1803 677 - 200 (kostenpflichtig / charges apply) Fax.: +49 (0) 1803 677 - 202

www.osram.com www.osram.de







G

١ آ

Selecting the installation location

F Maximum mounting height: 4,5 m $(\rightarrow \text{ detection area } \emptyset \text{ 21 m})$

- G Place devices that radiate heat outside of the monitoring cone.
- H Avoid drafts (e.g. from ventilators)



Attaching the motion detector to the ceiling

Note: The mounting adapter, available as an accessory, can be used for attachment. Follow the separate fitting instructions.

- ① Unlock and remove the plastic cover by turning it anticlockwise.
- ② Screw on the motion detector, using the mounting adapter as an aid, if necessary.
- (3) Connect the sensor; see the connection diagram.
- ④ Adjust the delay, if necessary; see the separate operating instructions.
- (5) Replace the plastic cover and lock it by turning it clockwise.





Connection diagram

- J Variant 1: switching of mains voltage
- K Switch contact
- L Load (ECG, lamps, etc.)

Μ



- M Variant 2: floating switching (example with EASY PB Cou-
- pler)
- K Switch contact
- N EASY PB Coupler
- O EASY control line
- P EASY control unit

Α	n	n	0	n	~	IV	
	v	IJ	C		u		

Technical data					
Operating voltage	120 V 277 V AC / 50-60 Hz				
Fuse	External 16 A				
Switch output	Floating switch contact				
Switch output load	Max. 5 A – 230 V				
capacity	Inductive load: 250 VA				
	Ohmic lamp: 1200 W				
	Max. number of ECGs:				
	QTP5:	10 pcs. 1x14-35 8 pcs. 1x54 / 2x14-35 6 pcs. 2x80 / 2x54			
	QTP8:	10 pcs. 1x58 6 pcs. 2x58			
	QT-FIT8: 10 pcs. 1x58 / 1x36 6 pcs. 2x58 / 2x36				
	QTi:	15 pcs. 1x28/54 10 pcs. 2x28/54 6 pcs. 2x35/49/80			
Operating temperature	-10 °C +70 °C				
Protection type	IP 20				
Dimensions (Ø x H)	115.6 x 39.9 mm				





. 39,9 mm **Dimensioned drawing**

The EMC requirements to EN 55015 are fulfilled. Conformity with the relevant EU directives is confirmed by the CE symbol.